


### Riser 2-Pipe Package (Top View)

S = Supply Riser  
 R = Return Riser  
 D = Condensate Riser  
 SA = Supply Air  
 RA = Return Air  
 EO = Exhaust Air To Outside  
 FI = Fresh Air Intake  
 EI = Exhaust Air Intake

Side connection riser can be off-set to front or back  
 Back connection riser can be off-set to left or right



### Riser 4-Pipe Package (Top View)

HS = Hot Water Supply Riser  
 HR = Hot Water Return Riser  
 CS = Chilled Water Supply Riser  
 CR = Chilled Water Return Riser

